

Charging

Indicate flash mode:

Red light flashes indicating charging

Red LED light indicates full charged

Forbiddance

- Please make sure to keep headset and USB plug closed.
- Do not expose the RSM to the flowing water such as waves and waterfall.
- Do not put RSM into salty water, electrolytic ionized water or soap water.
- Do not use it in the high temperature water and hot spring. The waterproof soft glue will result in water intake under the condition of high temperature.
- Do not open the battery cover in water or at extremely wet environment like the swimming pool or the bathroom.

7

- Do not open the battery cover before the machine is dried out.
- Do not wash the machine with cleaner containing chemical substance.
- The adhesive tape inside the battery cover is an important part. Please take care to open or close the battery cover to avoid destroying the adhesive tape. Please make sure that there is no any fragment on the adhesive tape in case of affecting the battery cover closed.
- The waterproof design of the RSM will lead to slight shake at the special conditions like little higher volume where the RSM shakes, not influencing the features of RSM.
- Please wash and wipe the machine if you drop the RSM into quagmire with no caution at outdoor activity.
- You can wash and wipe it if the phone drops on the beach.
- The counterpart might not able to hear of your voice if the RSM soak in water or the speaker wets. You must keep the speaker dried and ban using hair drier to blow it dry.

8

Security information

- Please use the adapter, charger, accessories and supplies recognized by RugGear.
- Do not put the RSM in overheat or overcooling place.
- Do not Put RSM into or aside the heater, microwave oven and cooker.
- Do not touch the RSM and charger with wet hand when charging.
- Please turn down the RSM at the gas station where the blast may happen.
- Please abide by all security warns and rules at limited place when using the RSM.
- Please follow the all safe warns and rules when driving.
- Do not use the RSM at hospital where the place may be affected by wireless electricity.
- If possible, please keep 15 centimeters far away from the pacemaker because the RSM may interfere with the pacemaker.

9

- Do not allow children and animals to bite, chew or suck the RSM or battery.
- Do not use the metal or liquid power element to touch the multifunctional touch and electrode.
- Do not use indicator near the eyes.
- Do not listen to talks or music with high volume in case of destroying hearing.
- Do not privately repair the RSM.
- Only qualified staff is permitted to repair the RSM. The damage to the RSM repaired by non qualified persons will not be guaranteed.

10

RugGear®

Quick Start Manual



Remote Speaker Microphone

RG RSM 1

Tip

Thank you for purchasing RugGear RSM (Remote Speaker Microphone). Please read this manual before using RSM, the company does not undertake any responsibility of man-made destruction and the consequences of improper use.

Security

1. Store in a dry place, away from moisture and corrosive materials.
2. Do not disassemble or damage this product.
3. Do not put the device in hot or cold places.
4. Do not place the product into the water, fire or corrosive liquids.
5. Please read the relevant parameters of the product, and the rational use of the product.



- ① PTT key: long press to use Bper
- ② SOS key: long press to use PTI/RugGear Assistant SOS function
- ③ Top LED light: status indicator light
- ④ Power key: press 3s to switch on RSM; press 8s to pair the RSM
- ⑤ volume up key: press 2s to turn up the volume
- ⑥ Front LED light: status indicator light, the same with top LED light
- ⑦ Volume down key: press 3s to turn down the volume
- ⑧ MIC hole
- ⑨ USB Port
- ⑩ Desk top charger port
- ⑪ Earphone port
- ⑫ Reset key: press to restart the RSM

Standards

RSM : 1PC
USB cable : 1PC
Manual : 1PC
charger : 1PC
Please use original accessories only.

Parameter

Batteries: Lithium-polymer battery
Input: DC 5V-500mA
Charging time: about 3.5H
PTT talk time: about 8H
Operating temperature: -15 °C ~ 50 °C
The features of dustproof and waterproof are tested and proved in the particularly controlled environment accordance with the international standard of IEC 60529.

The IP grade as follows:

0	No protection	0	No protection
1	prevent big object from entering the phone	1	The water drop has no effect on the surface of the phone
2	prevent middle substance from entering the phone	2	The water drop will not affect the surficial cover when the phone inclines to 15 degrees
3	Prevent little substance form entering the phone	3	There is no effect that water or rain drops to the surficial cover at the 60 degrees
4	Prevent the solid particles more than 1 mm size from entering the phone	4	There is no effect that the phone is sprayed by liquid from any direction
5	Prevent the harmful dust piled up	5	The phone can be washed by water
6	Entirely prevent dust entering the phone	6	The phone can be used in the cabin
		7	The phone can soak in water for a short time
		8	Be able to soak under the specific pressure for a long time

Although accorded with this kind of requirement ,it does not means your device will not be destroyed under any

condition. This product has tested by professional staff. Please avoid test it by yourselves.

Note: Please make sure to keep the battery cover, the screw lock, headset and USB plug closed aimed to accomplish the perfect dustproof and waterproof effect. Please refer to the installment method to the battery cover.

Using tips

Power on / off

In the power off mode, press the power on / off button and hold it for about 2 seconds until you hear a "beep" sound, then release the button, the blue light will flash. In power on mode, press the power on / off button, and hold for about eight seconds, until you hear a long "beep" tone, all luminous indicators will be closed to indicate Bluetooth RSM was switched off.

RG RSM 1 and Pairing

1. In the power off mode, press the power on button 8s, indicator light flashes red and blue alternately, RG RSM 1 enter pairing mode.
2. Turn on the phone's Bluetooth, search for the device. When the device name "RG RSM 1" appears, select and match. When LED indicators turn blue, the pairing succeeds.

Note: Please note that if PTT connect with RSM, following settings is needed.

PTT applications:

Select the Bluetooth call mode, and then you can talk through our RSM.

PTT

After paired, press the PTT key to control the conversation.